

Flexible Joint - Test Bench

Dehaeze Thomas

February 2, 2021

Contents

- 1 Flexible Joints - Requirements** **3**

- 2 Test Bench Description** **4**
 - 2.1 Flexible joint Geometry 4
 - 2.2 Required external applied force 5
 - 2.3 Required actuator stroke and sensors range 5
 - 2.4 First try with the APA95ML 6
 - 2.5 Test Bench 6

- 3 Experimental measurement** **8**

1 Flexible Joints - Requirements

	Specification
Axial Stiffness	> 200 [N/um]
Shear Stiffness	> 1 [N/um]
Bending Stiffness	< 100 [Nm/rad]
Torsion Stiffness	< 500 [Nm/rad]
Bending Stroke	> 1 [mrad]
Torsion Stroke	> 5 [urad]

2 Test Bench Description

The main characteristic of the flexible joint that we want to measure is its bending stiffness $k_{R_x} \approx k_{R_y}$.

To do so, a test bench is used. Specifications of the test bench to precisely measure the bending stiffness are described in this section.

The basic idea is to measure the angular deflection of the flexible joint as a function of the applied torque.




Figure 2.1: Schematic of the test bench to measure the bending stiffness of the flexible joints

2.1 Flexible joint Geometry

The flexible joint used for the Nano-Hexapod is shown in Figure 2.2. Its bending stiffness is foreseen to be $k_{R_y} \approx 20 \frac{Nm}{rad}$ and its stroke $\theta_{y,max} \approx 20 mrad$.

The height between the flexible point (center of the joint) and the point where external forces are applied is $h = 20 mm$.

Let's define the parameters on Matlab.

```
Matlab
kRx = 20; % Bending Stiffness [Nm/rad]
Rxmax = 20e-3; % Bending Stroke [rad]
h = 20e-3; % Height [m]
```




Figure 2.2: Geometry of the flexible joint

2.2 Required external applied force

The bending θ_y of the flexible joint due to the force F_x is:

$$\theta_y = \frac{M_y}{k_{R_y}} = \frac{F_x h}{k_{R_y}} \quad (2.1)$$

Therefore, the applied force to test the full range of the flexible joint is:

$$F_{x,\max} = \frac{k_{R_y} \theta_{y,\max}}{h} \quad (2.2)$$

```
Fxmax = kRx*Rxmax/h; % Force to induce maximum stroke [N] Matlab
```

And we obtain:

$$F_{max} = 20.0 [N] \quad (2.3)$$

The measurement range of the force sensor should then be higher than 20 N.

2.3 Required actuator stroke and sensors range

The flexible joint is designed to allow a bending motion of $\pm 20 \text{ mrad}$. The corresponding actuator stroke to impose such motion is:

$$d_{x,\max} = h \tan(R_{x,\max})$$

```
dxmax = h*tan(Rxmax);
```

$$d_{max} = 0.4 [mm] \quad (2.4)$$

In order to test the full range of the flexible joint, the stroke of the actuator should be higher than 0.4 mm . The measurement range of the displacement sensor should also be higher than 0.4 mm .

2.4 First try with the APA95ML

The APA95ML as a stroke of $100\text{ }\mu\text{m}$ and the encoder in parallel can easily measure the required stroke.

Suppose the full stroke of the APA can be used to bend the flexible joint (ideal case), the measured force will be:

```
Fxmax = kRx*100e-6/h^2; % Force at maximum stroke [N]
```

$$F_{max} = 5.0 [N] \quad (2.5)$$

And the tested angular range is:

```
Rmax = tan(100e-6/h);
```

$$\theta_{max} = 5.0 [mrad] \quad (2.6)$$

2.5 Test Bench

Note

- Manual Translation Stage
- Load Cell TE Connectivity [FC2231-0000-0010-L](#)
- Encoder: Renishaw [Resolute 1nm](#)




Figure 2.3: Schematic of the test bench to measure the bending stiffness of the flexible joints

3 Experimental measurement